

BETTER BONA FURNITURE PRODUCT USE INSTRUCTIONS

WE PROVIDE THIS SIMPLE INSTRUCTION TO GUIDE YOU HOW TO USE OUR PRODUCTS.

TRANSPORTATION

KEEP THE ARROW HEAD UPWARD DURING TRANSPORTATION, AND NEVER STACK FOR MORE THAN TWO LAYERS DURING DISTRIBUTING. HANDLE WITH CARE WHEN UPLOADING THE FURNITURE.

UNPACK AND INSTALLATION

WHEN UNPACKING, AVOID USING SHARP ARTICLES SO AS NOT TO DAMAGE THE PRODUCT INSIDE. TAKE THE PRODUCT WITH CARE, AND FIND THE ASSEMBLY INSTRUCTION(AI) AND HARDWARE PACKED IN ONE WHITE BOX. ASSEMBLE THE FURNITURE AS INSTRUCTED, AND KEEP THE AI FOR FUTURE USE.

MOVING THE FURNITURE

BEFORE MOVING THE FURNITURE, CHECK THE JOINTS BETWEEN SOFA LEGS AND FRAME, CABINET LEGS AND BODY, DOORS AND BODY, AND OTHERS. EMPTY CABINET OR DRAWERS AND LOCK THEM UP TO AVOID HURTING PEOPLE. WHEN MOVING THE FURNITURE, LIFT IT UP TO PREVENT THE FLOOR FROM BEING SCRATCHED OR DAMAGING THE FURNITURE LEGS.

SETTING THE FURNITURE

1. PLACE FUTURE ON AN EVEN FLOOR TO KEEP IT STABLE;
2. AVOID LONG-TIME DIRECT SUNSHINE OR HEAT ON FABRIC, LEATHER AND VENEER, SO THAT THE COLORS DO NOT FADE. LEATHER SOFA SHOULD BE PLACED IN A DRY AREA WITH GOOD VENTILATION;
3. THE ABOVE PRINCIPLE APPLIES TO WOODEN FURNITURE TOO, AS HEAT WILL MAKE WOOD CRACK AND COLOR FADE. THE ADEQUATE ROOM TEMPERATURE IS BETWEEN 18-24 DEGREE CELSIUS, THE MOISTURE BETWEEN 35% TO 40%. GREEN PLANTS AND ORNAMENTAL FISH HELP WITH MOISTURE. IF A MOISTURE MACHINE IS USED, NEVER AIM THE AIR AT THE FURNITURE;
4. NEVER USE THE FURNITURE OVER ITS CAPACITY TO AVOID THE DEFORMING OF DOORS.

USE THE FURNITURE

1. DO NOT APPLY HEAVY FORCE WHEN OPENING THE DOORS, BECAUSE THE ACTION WILL MAKE THE HINGES LOOSENING;
2. KEEP CHEMICALS SUCH AS ACID AND ALKALI AWAY FROM FURNITURE;

3. DO NOT PLACE SHARP ARTICLES ON GLASS-TOP AND HIGH GLOSSY FURNITURE TO AVOID POSSIBLE SCRATCHES;
4. DO NOT USE PLASTICS TO PROTECT WOOD-TOP TABLES, AS THIS ACTION WILL HARM THE PAINT;
5. USE SOME PROTECTION WHEN PLACE HOT STUFF ON THE TOP OF FURNITURE;
6. DO NOT JUMP ON THE SOFA, AS THIS WILL BREAK THE SEWING AND DAMAGE THE SHAPING;
7. HOW TO TAKE OFF THE SOFA COVER OFF?
TAKING OFF SOFA COVER REQUIRES SOME SKILLS. WE ADVISE YOU CONTACT YOUR LOCAL DEALER TO TAKE CARE OF IT FOR YOU. IF YOU HAVE TO DO IT BY YOURSELF, PLEASE FOLLOW THE STEPS GIVEN HERE:

A . TAKING OFF FRAME COVER

- REMOVE ALL THE PILLOWS AND CUSHIONS FIRST;
- UNZIP OR UNBOTTON THE SOFA FRAME COVER AT THE BOTTOM;
- USE THE NAPPED CLOTH PROVIDED WITH YOUR PURCHASE TO COVER THE BOTTONS UP TO AVOID POSSIBLE DAMAGE TO THE FABRIC;
- LIFT THE COVER INCH BY INCH FROM THE BOTTOM UP AND MOVE TOWARDS THE OTHER SIDE WHEN ONE SIDE IS DONE UNTIL THE COVER IS COMPLETELY OFF THE FRAME;
- DURING THE PROCESS, NEVER PULL HARD WITH FORCE AS IT WILL MAKE THE COVER DEFORM.

B. TAKING OFF THE PILLOWS AND CUSHIONS

- UNZIP THE PILLOWS AND CUSHIONS;
- PRESS HARD AND MAKE THE CUSHION AND PILLOW BODIES SMALLER, THEN TAKE THEM OUT OF THE COVERS.

C. PUT FRAME COVER BACK ON

- GET THE SIDE OF THE FABRIC CORRECT AND START FROM THE TOP ON BOTH SIDES;
- GO DOWN INCH BY INCH AND KEEP TWO SIDES AT THE SAME PACE;
- GIVE SPECIAL ATTENTION TO THE EDGES OF ARMREST AND BACK WHERE WRINKLES ARE POSSIBLE;
- ZIP OR BOTTON THE COVER UP AT THE BOTTOM.

D. PUT THE PILLOWS AND CUSHIONS BACK ON

- MAKE SURE THE SHAPE OF PILLOW AND CUSHION BODIES GO WITH THE SHAPE OF COVERS;
- PRESH THE SHAPE OF PILLOW AND CUSHION BODIES HARD AND INSERT THEM INTO THE COVER;
- PAT THE PILLOW AND CUSHION TO SHAPE THEM UP;
- ZIPPERS AND THE SIDE OF HOLES ARE TO BE PLACED BACKWARDS.